

VQ Vane Pumps for Mobile

-High performance intravane pumps for mobile applications



■ Symbol



■ How to order

(F3)	**V	**	A	(F)	.*	*	10	*
Prefix	Series	▲ Code	Port connection	Mounting	Shaft	Outlet position (viewed from cover end of pump)	Design 10	Rotation (viewed from shaft end of pump)
Omit-using:	20VQ	2,3,4,5,6,7,8,9,	A-SAE	Omit	1-Straight key	A-Opposite inlet port		
Antiwear oil		10,11,12,14,	4-Bolt	Flange	151-Spline	B-90° CCW from inlet		
water glycol	25VQ	10,12,14,15,	flange	mounting	86-HD.straight	C-In line with inlet		L-counter
fluid		17,19,21		F-Foot	key	D-90° CW from inlet		clockwise
F3:	35VQ	21,25,30,32,		mounting	11-Spline			R-clockwise
Phosphate		35,38,45						
ester fluid	45VQ	42,45,50,57,						
		60,66,75						